


SPIKE SUPPRESSOR



Basic Introduction

Nanocrystalline magnetic cores are widely used in switching power supplies, inverters, and EMC filtering. They effectively suppress spike noise from rapid current changes. A spike suppressor, made by winding one or a few copper wire turns around the core, is simple in structure and installation but highly effective.

high squareness ratio nanocrystalline cores have extremely low core losses and high magnetic permeability. At very small currents, they offer large inductance to block diodes' reverse reset current. The material also saturates quickly even with minimal current.



Application Schematic Diagram

The red part is the spike suppressor

Function and Basic Working Principle of Spike Suppressor




Figure 1

with out surge suppressor




Figure 2

with surge suppressor





Figure 3

Fig. 3 presents the nanocrystalline core's hysteresis loop. The spike suppressor works as follows:

- Before point 1 (current conducting), the core is saturated with very low inductance.
- When current turns off, the operating point moves to remanence
- The diode's reverse recovery effect causes current to decrease negatively.
- The material's ultra-high magnetic permeability boosts inductance, effectively suppressing the diode's spike current (see Figure 2).
- I_R is the theoretical reverse current spike, corresponding to point 3. The suppressor's high inductance prevents the core from reaching point 3, keeping it at reverse remanence point 4.
- The core is remagnetized to start a new cycle.

Basic Design and Calculation Formulas, Required Parameters



Taking the reverse voltage calculation–
method as an example:

$$U = \frac{d\varphi}{dt}$$

Integrating both sides of the equa–

$$\int U dt = \int d\varphi$$

$$\varphi = NBS$$

Where N = number of turns, B = magnetic flux density (taking remanence B_r), and S = core's effective cross-sectional area. Per the above formula, the area enclosed by points 2-3-4 equals the core flux required for surge suppression, i.e., $N \times B_r \times S > \dots$ (specific value determined by actual conditions).

Design Notes:

Nanocrystalline core's continuous operating temperature $\leq 150^\circ\text{C}$. Accurate calculation relies on correct diode reverse recovery time T_{rr} , which is affected by temperature and operating di/dt . di/dt is determined by circuit inductance (including the spike suppressor's variable inductance).

SPIKE SUPPRESSOR




认识纳米晶尖峰抑制器

纳米晶磁芯广泛应用于开关电源、变频器等领域，可抑制电流尖峰噪声；尖峰抑制器结构简单（磁芯绕少量铜线），安装便捷且抑制效果显著。

纳米晶高矩形比磁芯具备两大关键特性


- 极低磁芯损耗与极高磁导率，电流较小时能产生超大电感量，可阻挡二极管反向复位电流。
- 易饱和，小电流下快速饱和



—尖峰抑制器应用简图—
红色标注为尖峰抑制器


尖峰抑制器工作原理与作

电流抑制效果对比



对比项	未加装尖峰抑制器	加装尖峰抑制器
电流波形特征	二极管反向尖峰电流(I _R)干扰电路	大幅抑制尖峰电流，曲线平滑
核心差异	难挡二极管反向恢复尖峰	高电感阻反向电流，软恢复实现

磁滞回线工作原理



- 电流导通阶段(工作点1之前)**
 磁芯饱和、电感量低，不影响正常电流传输。
- 电流关断阶段(工作点2)**
 电流关断后，工作点至剩磁点，二极管反向恢复使电流向。
- 尖峰抑制阶段(避开工作点3)**
 纳米晶材料磁导率骤升、电感量增大，阻止磁芯达反向尖峰工作。
- 循环阶段(工作点4)**
 磁芯停留在反向剩磁点4，随后重新磁化，进入下一个工作循环。

基本设计和计算公式

核心计算公式(以反向电压计算为例)

公式类	公式内容	参数说明
反向电压基础公式	$U = \frac{d\phi}{dt}$	反向电压、磁通、时间
积分推导公式	$\int U dt = \int d\phi$	通过积分计算磁通变化量
磁通计算式	$\phi = NBS$	匝数、磁通密度(取剩磁 Br) 铁芯有效截面积
抑制条件公式	$N \times Br \times S > \int U dt$	2-3-4 点包围面积需小于 $N \times Br \times S$, 保障浪涌有效抑制

设计关键注意事项

温度耐受上限

纳米晶磁芯连续工作温度 $\leq 150^{\circ}\text{C}$ ，需兼顾散热设计。

关键参数精度控制

二极管反向恢复时间 T_{rr} 为关键参数，受温度、线路 di/dt (电流变化率) 影响， di/dt 由线路电感(含尖峰抑制器变化电感)决定，需精准测算。